

















MODEL: B605 B606

(1)x1	(2)x1	(3)x1 (L)x1 (R)
		
Back Cushion	Seat Cushion	Left- Arm Right- Arm
(4)x 1	(5)x1	(6)x1
		
Mechanism	Gas Lift W/ Cover	Base
(7)x 5	<p>(A)*6   M6*30 Arm Screws</p> <p>(B)*2  M8*30 Mechanism Screws</p> <p>(C)*2  M8*22 Mechanism Screws</p> <p>(D)*2   M6*30 Back Bar Screws</p> <p>(E)*2   M6*36 Back Bar Screws</p>	
	Caster	



**Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.**



B606



B605