
Thankyou for your purchase!



ASSEMBLY INSTRUCTIONS

Before You Begin: Phillips screwdriver required for assembly (not included).

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury. DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.


Warning:


CHOKING HAZARD - Small Parts. Adult Assembly Required. DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.

PARTS LIST






HARDWARE LIST


ITEM	DESCRIPTION	QTY
1	Ø8*30mm WOOD DOWELS	24 pcs
2	Ø6*34mm CAMLOCK	27 pcs
3	Ø15*9mm CAMLOCK	27 pcs
4	#3.5*15mm SCREW	20 pcs
(5)	20x18x14mm Shelf Pin	4 pcs
6	#3.5*12 SCREW <	4pcs
7	Hinge	4 pcs

ITEM	DESCRIPTION		QTY
8	Handle		2 pcs
9	5/32"*22mm Bolt		4 pcs

INSTALLATION

STEP 1







② Ø6*34mm CAMLOCK 13pcs



STEP 2





① WOOD DOWELS 2pcs

