






















WA-3074 - BOTAI MODEL PARTS

ASSEMBLY INSTRUCTION

<p>(1)X1</p> 	<p>(8)X1</p> 	<p>①</p> 		<p>②</p> 
<p>(2)X1</p> 	<p>(9)X5</p> 	<p>③</p> 		<p>④</p> 
<p>(3)X1</p> 	<p>(10)X1</p> 	<p>⑤</p> 	<p>⑥</p> 	
<p>(4)X1</p> 	<p>(11)X4</p> 	<p>⑦</p> 		
<p>(5)X1</p> 	<p>(12)X2</p> 			
<p>(6)X1</p> 	<p>(13)X4</p> 			
<p>(7)X1</p> 	<p>(14)X2</p> 			
	<p>(15)X1</p> 